

W001/4200 BMW R1200GS Two-Finger Levers Silver

July 2023

Why do you want to fit this part?

- To make the use of the front brake and clutch lever more comfortable without pinching your fingers when pulling the clutch.

This part fits on the following motorcycle:

- BMW R1200GS Air Cooled 2006-2013

Part list:

- 1 x Two-Finger Front Brake Lever
- 1 x Two-Finger Clutch Lever
- 2 x 6mm Inner Diameter Bushes
- 2 x 7mm Inner Diameter Bushes

Tools needed:

- T25 Torx
- 8mm Spanner
- Hammer
- 8mm Drill Bit
- Flat Screwdriver



Fitment Instructions:

Step 1: Remove the top screw of the brake lever using a T25 Torx and an 8mm spanner.

Step 2: Pull or remove the standard lever outwards from the casing. Be careful not to loose the inside spring once removed.



Step 3: Lightly punch the bush out of the hole where the screw in step 1 fits into using a hammer and an 8mm drill bit.



W001/4200 BMW R1200GS Two-Finger Levers Silver

Step 4: Remove the back part (cap part) of the knob of the adjustment screw using a flat screwdriver. Wedge it between the cap and the lever.



Step 5: Unscrew the adjuster from the original lever. Check what size bush (6mm or 7mm) is applicable to your bike's adjuster screw and screw the chosen bush into the Wild@Heart lever using a Torx spanner. Press the adjuster knob back at the back.

Step 6: Re-assemble the bush in step 3 above onto the new lever. Be careful not to loose the spring.



Step 7: Install the Two-Finger Lever using the T25 Torx and 8mm spanner as in Step 1.

Step 8: Ensure all bolts are fastened and the brake lever set properly before riding.

Repeat Steps 1 to 8 for the Clutch Lever.

Note: Make sure all bolts are fastened on both sides and the levers fitted properly before riding. Enjoy the trip!

All parts and accessories are fitted at own risk. Wild at Heart Adventure (Pty) Ltd. and the directors do not take any responsibility for any damage or injury due to the fitment or use of the accessories.