

---

## W005/4200 BMW F800/650GS TWIN TWO-FINGER LEVERS SILVER

---

July 2023

### Why do you want to fit this part?

- To make the use of the front brake and clutch lever more comfortable without pinching your fingers when pulling the clutch.

### This part fits on the following motorcycle:

- BMW F800/650GS Twin 2008+

### Part list:

- 1 x Two-Finger Front Brake Lever
- 1 x Two-Finger Clutch Lever
- 1 x 8mm Inner Diameter Bush
- 1 x 7mm Inner Diameter Bush

### Tools needed:

- T25 Torx
- 8mm Spanner
- Hammer
- 8mm Drill Bit
- Flat Screwdriver

### Fitment Instructions:

---




#### Two-Finger Clutch Lever

---


**Step 1:** Release the clutch cable at the bottom.



## W005/4200 BMW F800/650GS TWIN TWO-FINGER LEVERS SILVER

<p><b>Step 2:</b> Unscrew the bolt at the top of the clutch lever using a T25 Torx for the top and an 8mm spanner on the bottom.</p>	
<p><b>Step 3:</b> Release the cable from the lever and remove the lever.</p>	
<p><b>Step 4:</b> Punch the bush out with the 8mm drill bit.</p>	
<p><b>Step 5:</b> Pull out the black component. Be careful not to loose the inside spring.</p>	
<p><b>Step 6:</b> Insert spring into new lever and re-install the clutch lever and cable.</p>	
<p><b>Step 7:</b> Ensure all bolts are tightened and the clutch cable is in good working order before riding.</p>	




## Two-Finger Front Brake Lever

<p><b>Step 1:</b> Remove the top screw of the brake lever using a T25 Torx and an 8mm spanner as in step 1 for the Clutch Lever.</p>	
<p><b>Step 2:</b> Pull or remove the standard lever outwards from the casing.</p>	

---

## W005/4200 BMW F800/650GS TWIN TWO-FINGER LEVERS SILVER

---

<p><b>Step 3:</b> Lightly punch the bush out of the hole where the screw in step 1 fits into using a hammer and an 8mm drill bit. (Be careful not to loose the inside spring once removed.)</p>	
<p><b>Step 4:</b> Remove the back part (cap part) of the knob of the adjustment screw using a flat screwdriver. Wedge it between the cap and the lever.</p>	
<p><b>Step 5:</b> Unscrew the adjuster from the original lever and install in Two-Finger lever. Press back the adjuster knob.</p>	
<p><b>Step 6:</b> Re-assemble the bush in step 3 above onto the new lever. Be careful not to loose the spring.</p>	
<p><b>Step 7:</b> Install the Two-Finger Lever using the T25 Torx and 8mm spanner as in Step 1.</p>	
<p><b>Step 8:</b> Ensure all bolts are fastened and the brake lever set properly before riding.</p>	

All parts and accessories are fitted at own risk. Wild at Heart Adventure (Pty) Ltd. and the directors do not take any responsibility for any damage or injury due to the fitment or use of the accessories.