

W010/4205 KTM 1290 SUPER ADV 2021+ TWO-FINGER LEVERS SILVER

July 2023

Why do you want to fit this part?

- To make the use of the front brake and clutch lever more comfortable without pinching your fingers when pulling the clutch.

This part fits on the following motorcycle:

- KTM 1190/1290 Adventure

Part list:

- 1 x KTM Two-Finger Front Brake Lever
- 1 x KTM Two-Finger Clutch Lever

Tools needed:

- 4mm Allen Key
- Torx 20
- 8mm Spanner
- 10mm Spanner
- 2mm Drill Bit
- 8mm Drill Bit
- 10mm Drill Bit
- Flat Screwdriver



Fitment Instructions:


Brake Lever

Step 1: Unscrew the indicated screw using the 4mm Allen Key at the top and the 10mm spanner at the bottom. Remove the bolt when done.






Step 2: Pull the lever towards the outside to remove it. If necessary, loosen the handguard if need be.

W010/4205 KTM 1290 Super ADV 2021+ Two Finger Levers Silver

| | |
|--|--|
| <p>Step 3: Rebuild the OEM components on the Two Finger Lever:</p> <ul style="list-style-type: none">• Remove C-Clip indicated in red and pull out the adjuster knob (mind the washer)• Use the back of a 10mm drill bit to push out the silver bush indicated in yellow– you might have to lightly punch it out• Rebuild these components into the Two Finger Lever and reinstall. |  |
|--|--|

Clutch Lever

| | |
|---|--|
| <p>Step 1: Unscrew indicated screw and remove by using the Torx 20 at the top and the 8mm Spanner for the bottom nut.</p> |  |
| <p>Step 2: Pull the lever outwards to remove (no cables – it is all hydraulic)</p> | |
| <p>Step 3: Push silver bush indicated in yellow out by using an 8mm drill bit.</p> |  |
| <p>Step 4: Punch pin (indicated in red) out using the 2mm drill bit – It is important to catch the pin as it comes out, so it does not get lost.</p> |  |
| <p>Step 5: Unscrew the adjuster knob.</p> | |
| <p>Step 6: Rebuild the components onto the 2 Finger Lever.</p> | |
| <p>Notes:</p> <ul style="list-style-type: none">• Ensure the spring is in the correct position by “pulling” it outwards using a flat screwdriver.• Ensure the locating pin is in place. | |

Note: Make sure all bolts are fastened on both sides and the levers fitted properly before riding. Enjoy the ride!

All parts and accessories are fitted at own risk. Wild at Heart Adventure (Pty) Ltd. and the directors do not take any responsibility for any damage or injury due to the fitment or use of the accessories.